



DocuMate

Phasec 2200/D62 Reporting Utility

Purpose

Documate is a simple Instrument to PC data transfer utility for the Phasec D62 and Phasec 2200 instruments. It enables the user to copy screen images and settings onto the Windows Clipboard for pasting into standard Windows applications such as MS Word, Write or Wordpad. Alternatively data may be saved to Disk. Screen images and settings may also be printed directly form DocuMate to any connected Windows printer.

Used With:

Phasec 2200 plus cable 47A004

Or

Phasec D62 plus cable 33A084

Relevant Specifications

Requires	Windows 95/98
Text Files	Saved as rich text format (rtf)
Images	Saved as Windows Bit Map (bmp)
Printing	Uses windows printer driver
Communications	RS232 at 9600 baud

HOCKING

Hocking NDT Ltd • 129-135 Camp Road • St Albans • Hertfordshire • AL1 5HL • UK
 Tel: +44 (0)1727 795500 • Fax: +44 (0)1727 795400 • info@hocking.com • www.hocking.com